



SAFE082A – FFP2 2022FD EVOLUTION FOLDED RESPIRATOR 20's

TECHNICAL DATA

APPLICATION

This product is intended to be used to provide respiratory protection to the wearer from a range of solid and non-volatile liquid airborne particles such as dust, smoke and aerosols that result principally from the disintegration or general processing of minerals and other materials.

CHARACTERISTICS

- Triple layered construction for maximum protection.
- Lightweight for easy breathing and speaking.
- Foam nose seal with adjustable aluminium nose clip and welded elastic ear loops ensuring a comfortable, contoured and secure fit.
- SANS50149:2003 approved

WARNINGS AND LIMITATIONS

This product should only be worn where the employer has determined that FFP2 Respirators are appropriate for the workplace hazards and where the wearer has been trained in the products use.

This product is not intended for use as a surgical mask

This product is intended for single use only to a maximum of 1 work shift (8 hours) at a time

Use before expiry date indicated on pack.

The efficiency of the filter deteriorates as the filter medium becomes clogged especially in the presence of oil and oil mists.

Facial hair, certain hairstyles and other facial characteristics may impact on facial seal and thus the effective use of this product. A facial fit test should be conducted prior to use (see fitting instructions).

Do not attempt to disinfect, clean, alter, modify or repair this product in any way.

Cape Town (021)514 1400	Vredenburg (022)713 1538	Durban (031)274 0200	Richards Bay (035) 789 5735	Middleburg (013)246 2402	Midvaal 0861 000 751	Polokwane (015)297 6314	Port Elizabeth (041)453 2178	Swaziland +2682(518)6396	Zambia +260211847911
----------------------------	-----------------------------	-------------------------	--------------------------------	-----------------------------	-------------------------	----------------------------	---------------------------------	-----------------------------	-------------------------

Use only in accordance with the provided instructions, labels and limitations relating to this product.

This product must be replaced subsequent to:

- a single work shift
- dust penetration occurring
- mask becoming damaged

Report immediately to the Health and Safety representative should any of the following occur:

- Breathing becomes difficult
- Dizziness or other signs of distress

Do not use the product in the following conditions:

- Atmospheres containing explosives, radioactive substances, fumes, toxic gases, enzymes or vapours
- Atmospheres where there may be a deficiency of oxygen
- Atmospheres where the particulate concentration exceeds 10 x the PEL Permissible Exposure Level

FITTING INSTRUCTIONS



1. Hold the respirator in your hand with the hollow side facing upwards and the nose clip at your fingertips, allowing the ear loops to hang freely over the edges of your hand.
2. Place the bottom edge of the mask below your chin and press the mask firmly against your face, covering your mouth and nose, with the nose clip at the bridge of your nose.
3. Pull the ear loops over your ears, one at a time with your free hand while holding the respirator firmly in place with the other.
4. Pinch the nose clip to bend around the nose creating a snug seal.

FIT TEST: Cup both hands over the respirator and exhale suddenly and forcefully. If air escapes around the nose, adjust and tighten the nose clip to the shape of the nose.. If air escapes around the edges of the respirator, reposition the ear loops for a better fit. Retest the seal and repeat the procedure until the respirator is sealed properly.

DO NOT enter the hazardous environment if a proper fit cannot be achieved.

Disclaimer: The information provided in this data sheet is correct to the best of our knowledge. Information given is designed only as a guidance for safe handling use.